
New features of Soneco CC-B 3 alarm button

Following changes are related to new hardware/software version of the device. New model can be identified by the identification label which says: "Model: Soneco CC 3".

1. Changes to device programming:

In the new version of the device you can not enter to the standby mode directly from the programming mode. Exiting from the programming mode is done by briefly pressing the function button. After pressing the function button the device is powered off. It can be powered on after about 10 seconds, when all the leds have blinked once.

Numbers can be saved to the memory same as before. Number saving is done with SMS message <<<number1;number2;number3>>> in the programming mode.

2. Change to charging indications:

Charging of the device is shown by brightness of the yellow led. When charging goes on yellow led gets dimmer. When charging is finished the device gives sound indication and resumes the state as it was before connecting the charger.

In the new model version it is not necessary to remove the charger if the device enters to pre-charging mode since charging is monitored and controlled by software.

3. Extra features:

In the new software version it is possible to assign following extra features. Extra features can be Enabled/Disabled in programming state:

A1/A0 Audio indications Enabled/Disabled. When enabled most light indications are confirmed with different kinds of beeping sounds. This feature has already enabled in factory settings in model CC-B.

E1/E0 Emergency call setting Active/Disabled. If Emergency call setting is disabled, over ten seconds long button press is same as five seconds long button press and the device is powered off.

S1/S0 Enable/Disable programming state: During startup there is no 5s waiting. The programming state can be entered by sending sms <<<PRG>>> to device which is in READY state. The SMS have to be sent from one of the numbers saved to devices memory.

F1/F0 Force start Enabled/Disabled: When feature is enabled the device is automatically powered on to READY state, if battery capacity is over 60%.

P1/P0 Power off setting Enabled/Disabled: If the setting is enabled the device can not power off. (1-9s long button press is the same as short button press → over 10s long button press still makes emergency call, if **E1** enabled. If **E0** is set the device transits to number select/call state)

N0/N1/N2 Caller ID sending settings. **N0**: Use operator setting **N1**: Caller ID disabled to the receiver. **N2**: Caller ID is always sent to the receiver.

By default emergency calls are enabled and all other extra features are disabled. Extra features can be changed one by one (example <<<S1>>>) or change all settings with one message (example: <<<E0S1F0P1>>>).

For example if it is preferred to have a device which just makes call/s to pre-programmed number/s. SMS message <<<E0S1F1P1>>> have to be sent to the device which is in programming state. Extra features are enabled when setting is set to "1" and disabled when setting is set to "0".

Note. All letters are capital letters! Extra features saving indications are the same as number saving indications.